

VersaFill® 3 Bottle/Bucket Fill

967100, 967200, & 967300



Select bottle fill product by turning dial to desired product



Put bottle on fill tube and push left button for bottle fill



Select bucket fill product by turning dial to desired product



Push right button for bucket fill



Spartan Chemical Company, Inc.
www.spartanchemical.com

SERVICE/TECHNICAL SUPPORT
1-800-537-8990

SPARTAN MEDICAL EMERGENCY
1-888-314-6171

VersaFill® 3 Llenado de botella/cubeta

967100, 967200, & 967300



1 Seleccione con el dial el producto con el que desea llenar la botella



2 Inserte la botella al tubo de llenado y presione el botón izquierdo para llenar la botella



3 Seleccione con el dial el producto con el que desea llenar la cubeta



4 Presione el botón derecho para llenar la cubeta



Spartan Chemical Company, Inc.
www.spartanchemical.com

SERVICIO DE ASISTENCIA/TÉCNICO
1-800-537-8990

EMERGENCIA MÉDICA SPARTAN
1-888-314-6171

VersaFill® 3 Reposición del contenedor vacío

967100, 967200, & 967300



1
Abra la cerradura del gabinete y retire la cubierta



2
Saque el contenedor vacío y desenrosque la tapa



3
Enjuague y vuelva a usar el contenedor vacío



4
Retire la tapa, insértele el tubo de absorción, y enrosque la tapa acoplada



5
Vuelva a poner el contenedor en el dispensador



6
Ponga de nuevo la cubierta del dispensador y cierre la cerradura



Spartan Chemical Company, Inc.
www.spartanchemical.com

SERVICIO DE ASISTENCIA/TÉCNICO
1-800-537-8990

EMERGENCIA MÉDICA SPARTAN
1-888-314-6171

VersaFill® 3 Empty Container Replacement

967100, 967200, & 967300



1 Unlock cabinet and remove cover



2 Remove empty container and unscrew cap



3 Rinse and recycle empty container



4 Remove cap, insert pick-up tube, and attach mating cap



5 Insert container into dispenser



6 Replace dispenser cover and lock



Spartan Chemical Company, Inc.
www.spartanchemical.com

SERVICE/TECHNICAL SUPPORT
1-800-537-8990

SPARTAN MEDICAL EMERGENCY
1-888-314-6171